

ELMO Document Projector



The ELMO document projector enables you to display documents and objects for participants to view during a videoconference event. Displaying medical records, prescriptions and site signs as well as annotating documents during an event are examples of uses for the ELMO projector.

Step 1: Ensure that the projector is plugged in and turned on.



Step 2: Plug the appropriate video cable into the back of the projector.



Step 3: Choose the appropriate video source using the remote control.



Projection Functionality:

The upper lamp button allows you to turn the upper light on. This could be used to share printed documents similar to using an Overhead. The lower lamp turns the base light on and is ideal for sharing transparencies.

The zoom feature allows you to zoom in by using the Tele button and zoom out by using the Wide button.

The auto focus ensures that the projector switches to the auto focus mode.

